



NOTE: VULKEM 950NF MAY BE USED AS A TOPCOAT IN AREAS WITH NO U.V.

THERE ARE SEVERAL TECHNIQUES FOR INSTALLATION AROUND DRAINS. YOU MAY ALSO TAKE THE VULKEM MEMBRANE DOWN INTO THE DRAIN ASSEMBLY. THE DRAIN ASSEMBLY MUST BE BLOCKED IF THIS APPLICATION IS PREFERRED. THE METAL OR PLASTIC DRAIN SHOULD BE SCUFFED AND CLEANED AND PRIMED WITH TREMCO'S TREMPRIME NON POROUS PRIMER.



3735 Green Road, Beachwood, OH 44122  
Phone : 866-209-2404

Detail: Vulkem Pedestrian System at Drain

Sheet Number:

File Name:

DC-P-D-01

This detail is intended for conceptual purposes only.

Drawn by: KAB

Checked by: WH

Scale: None

Date: 4/21/2020